


User Account Control

(Applies to all VMS systems running Windows 7, Windows Server 2008 & Windows Vista)


User Access Control interferes with IPServer, and can cause issues with writing to the database, and starting and stopping the service using the IPServerManager. Follow the steps outlined to disable UAC.

Click **START** and select **Control Panel**.

In **Control Panel**, select **User Accounts**.



When the **User Accounts** window opens, select “**Change User Account Control Settings**”.



Once the User Account Control Settings window opens, slide the slider bar on the left, down to “Never Notify”. This will disable the User Account Control restriction, which is known to cause issues with the performance of IPServer.

