## [SENTRY VMS – SUPPORTED ACCESS CONTROL SYSTEMS]

Access Control System	Integration Type	User Interface	Live Window Pop Up on Event	Notification on Event	Display Photo on Badge Scan	Lock/Unlock Doors	Doors incorporated into Facility Maps	Event Logging in VMS Server	Supports Lane Viewer	Supports Access View
Infinias	VMS Client	Using SENTRY VMS Client, administrators can create camera/door associations, add/edit doors, Rules Manager condition.	YES	YES	YES	YES	YES	YES	YES	YES
Open Options	VMS Client	Using SENTRY VMS Client, administrators can create camera/door associations, add/edit doors, Rules Manager condition.	YES	YES	YES	YES	YES	YES	YES	YES
IMRON / MonitorCast	VMS Client	Using SENTRY VMS Client, administrators can create camera/door associations, add/edit doors, Rules Manager condition.	YES	YES	YES	YES	YES	YES	NO	YES
Blackboard	VMS Client	Using SENTRY VMS Client, administrators can create camera/door associations, add/edit doors, Rules Manager condition.	YES	YES	YES	NO	YES	YES	YES	YES
Isonas	VMS Client	Using SENTRY VMS Client, administrators can create camera/door associations, add/edit doors, Rules Manager condition.	YES	YES	YES	YES	YES	YES	YES	YES
Paxton	VMS Client	Using SENTRY VMS Client, administrators can create camera/door associations, add/edit doors, Rules Manager condition.	YES	YES	YES	YES	YES	YES	YES	YES

## **IPVIDEO CORPORATION**

## [SENTRY VMS – SUPPORTED ACCESS CONTROL SYSTEMS]

Access Control System	Integration Type	User Interface	Live Window Pop Up on Event	Notification on Event in VMS Client	Display Photo on Badge Scan	Lock/Unlock Doors	Doors incorporated into Facility Maps	Event Logging in VMS Server	Supports Lane Viewer	Supports Access View
S2 Net Box	(OVID) Database Connection	Live and Recorded video presented to user via the S2 Client Interface.	YES	NO	NO	NO	NO	YES	NO	NO
RS2	Command Line	Live and Recorded video presented to user via pop up windows launched from RS2 client.	YES	NO	NO	NO	NO	NO	NO	NO
DSX	Ini File	DSX integration will offer both Live and Recorded video as well as the ability to use your camera's PTZ presets.	YES	NO	NO	NO	NO	NO	NO	NO
SureView Systems	Access Control Client Interface	Live and Recorded video presented to user via the Sureview Interface.	YES	NO	NO	NO	NO	NO	NO	NO
AMAG	Access Control Client Interface	Live and Recorded video presented to user via the AMAG Interface.	YES	NO	NO	NO	NO	NO	NO	NO
Lenel	Access Control Client Interface	Live and Recorded video presented to user via the Lenel Interface.	YES	NO	NO	NO	NO	NO	NO	NO